



Anziehvorschrift für Zylinderkopf		128.230 passend für / suitable for adaptable à / adaptable a Opel	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
 803.060 M 10 x 153			
Anziehen/ Tightening/ Serrage/ Apriete		* 25 Nm ➤ 90° ➤ 90° ➤ 90° ➤ 45°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø: 81,5 mm; $\frac{1}{2}$: 0,45 mm			
Mot: X 18 XE1, Z 18 XE / Z 18 XEL 1,8 ltr			
Corsa C 2001 ➔, Vectra B 1996 ➔ Vectra C 2002 ➔, Astra G / Zafira 1998 ➔			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*128.230*	