

Anziehvorschrift für Zylinderkopf		288.481 passend für / suitable for adaptable à / adaptable a Opel	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
103168 75249				
Anziehen/ Tightening/ Serrage/ Apriete	2,3 D: * 30 Nm 60 Nm 100 Nm ★ 15 min 140 Nm 1000 km ☐ 140 Nm	2,3 TD / DTR / YDT * 50 Nm 100 Nm ➤ 135° ★ 15 min ➤ 30° ➤ 30°	2,3 YD /DT: * 50 Nm 100 Nm ➤ 135° ★ 15 min ➤ 30°	
Zeichenerklärung / Explanations / Explication / Explicacion				
★	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 93,2 mm;✚: 1,3 mm 1 Loch / Hole/ Trou				
Mot: YD,YDT,YTD,DTR 2,3 Ltr. Diesel, Turbo-Diesel 48*74 kW (65-100 PS)				
Omeha A, Rekord E, Senator A, Frontera A ab 1973➔				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*288.481*	