



Anziehvorschrift für Zylinderkopf		593.930 passend für / suitable for adaptable à / adaptable a VW / AUDI / SEAT / SKODA	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 351.900 M 12x1,75x206				
Anziehen/ Tightening/ Serrage/ Apriete	* 30 Nm 70 Nm ➤ 90° ➤ 90° ➤ 90°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor 2,0 TDI EA288 1,55 mm / 1 Loch / hole CVCA, CRVA, CRVC, CRLB, CRLC, CRBC, CRBD, CRFA, C CRUA, CSUA, CSUB, CSUE, CSUD, CKFB, CKFC, CRMB, C CNHA, CNHC, CUUA, CUUB, CUUC, CUUD, CUUE, CUUF, D DFSB, DFSC, DFSD, DFSE, DFSF, CUXA, CUWA, CUVB, C CUVC, CUVD, DFLA, DFLD, DFMA, DFUA, CRVA, CYKB, C DFEA, DFHA, DEUA, DEUB, DESA, CZHA, CZJA, DEUA, D DETA, DETB, DFVA, CNHA				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*593.930*	