

Assembly instructions for wheel bearing kit 713 6100 20

Vehicle

manufacturer: Audi, Seat, VW

Models:

Audi: A3, TT

Seat: Leon, Toledo II, Octavia

VW: Bora, Golf IV, New Beetle

Item no.: 713 6100 20 (KIT)



Image 1: 713 6100 20 – FAG wheel bearing kit

When replacing the wheel bearing in the above wheel bearing kit, observe the correct procedure when tightening the twelve point nut.

Assembly procedure: kit 713 6100 20 for vehicles with twelve point nut.

Remove any paint residue and/or corrosion in the thread/splines of the external joint.

Before inserting the prop shaft, ensure the following are coated with oil:

- Splines of the external joint
- Thread of the external joint
- Splines of the wheel hub
- Bearing surface and thread of the twelve point nut.
- Tighten the twelve point nut to 200 Nm and unscrew half a turn
- Turn the wheel hub 180°
- Then turn again to 50 Nm + 60°

Contents - wheel bearing kit 713 6100 20:

- 1 x wheel bearing
- 1 x twelve point nut
- 1 x retaining ring
- 1 x nut
- 1 x nut
- 1 x nut
- 1 x assembly paste



Note the specifications of the vehicle manufacturer!

Appropriate spare parts can be found in our on-line catalogue at www.Schaeffler-Aftermarket.com or in RepXpert at www.RepXpert.com.

Issued 11.2009

FAG 0012

Technical subject to change

© 2009 Schaeffler Automotive Aftermarket oHG

For further information:

Phone: +44 (0) 14 32 264 264*

Fax: +44 (0) 14 32 375 760

Info@LuK-AS.co.uk

www.Schaeffler-Aftermarket.com

* Calls from within the UK 08457 001100

FAG