

Anziehvorschrift für Zylinderkopf		540.510 passend für / suitable for adaptable à / adaptable a Toyota	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
7 5 8 6 2 3 1 4 4 1 3 2 6 8 5 7				
Anziehen/ Tightening/ Serrage/ Apriete * ➤ ➤ 34 Nm 90° 90°				
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
MC 3VZFE, 3,0 ltr. 24V 138 KW Toyota Camry 03.92-07.96 Toyota Camry Station Wagon 06.91-08.96				
MC 2VZFE, 2,5 ltr. 24V 118 KW Toyota Camry 01.90-05.91 Toyota Camry Station Wagon 02.88-05.91				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*540.510*	