



Fig. 1: Retaining device with bayonet connector



Fig. 2: Retaining device with plastic lock

Actuating cables with an automatic adjustment mechanism are retained with a bayonet connector (Fig. 1) or with a white plastic band (Fig. 2).

Actuating cable with bayonet connector

1. Install actuating cable.
2. Release retaining device (bayonet connector).
3. Remove retaining device (bayonet connector).

➔ The actuating cable automatically adjusts after the clutch pedal is actuated.



Fig. 3: Retaining device released



Fig. 4: Retaining device removed

Actuating cable with plastic band

1. Install actuating cable.
2. Release retaining device (plastic band).
3. Remove retaining device (plastic band).

➔ The actuating cable automatically adjusts after the clutch pedal is actuated.



Fig. 5: Retaining device released



www.zf.com/serviceinformation