



Item no. 35016 01




Fig. 1: Supporting joint

- |   |                   |   |                |
|---|-------------------|---|----------------|
| 1 | M20x1 Special Nut | 4 | M18x1.5 Thread |
| 2 | M20x1 Thread      | 5 | M18 x 1.5 Nut  |
| 3 | Supporting joint  |   |                |

### WARNING

Fastening parts (screws, nuts etc.) are safety-relevant parts!  
 The use of the wrong fastening parts may lead to damage and serious accidents.  
 Only use fastening parts with the correct measurements and strength values!

Fasten the supporting joint (3) with the following parts:

- Nut (5) M18 x 1.5 (included in the kit)
- Special nut (1) **M20 x 1** Item no. 35347 01 (order separately)

Apply the specified tightening torque when installing the supporting joint.



[www.zf.com/serviceinformation](http://www.zf.com/serviceinformation)